

Tel: 352-602-6404 info@milkttronics.com

How to calibrate a VOA on cream FAT measurement?

The VOA needs to be in the process when the cream product is running at approximately 40%.

Press ESC for a few seconds

1/SYSTCONF is displayed



2/Goto OUTPCONF



ENTER

3/Goto to USERPNTS



ENTER

4/Goto POINT 2



ENTER

5/Goto EDIT



ENTER

Tel: 352-602-6404 info@milktronics.com

Current value



Needs to be changed to 20000.000

Enter value 20000.000



6/Press ENTER a few times until you reach the next page

Current value



Change value to 60.000

Enter value 60.0000



ENTER

SAVE?



ENTER

ESC 3 times to get back to normal display

Process Adjustment Instructions (Step 5 – Point 2 FU):

- The percentage displayed during the process may not accurately reflect the LAB value.
- At **Step 5**, the **Point 2 FU** must be adjusted accordingly:
 - If the **LAB value is higher** than the process reading, **increase** the FU.
 - If the **LAB value is lower** than the process reading, **decrease** the FU.

For Technical support please contact Sylvain Dehec sylvain.dehec@milktronics.com ph :6786199268